

Installation instructions for PZ4AL-2793-00, PZ4AL-2794-00
Under Run Protective Shield Fuel Tank

TOYOTA RAV4



LEXUS NX



Model year:

RAV4 - 2012 - 2015 -

NX

2014

Applicability:

ZSA44L-ANFXK; ZSA44L-ANXXK
ZSA44L-ANXGK; ZSA44L-ANYXKX
ZSA44L-ANYMKX; ALA49L-ANTGXX
ASA44L-ANTGKX; ASA44L-ANTMKX
ALA49L-ANTMXX; ZSA42L-ANYXKX
ZSA44L-ANFMKX; ZSA42L-ANYMKX
ZSA42L-ANFXKX; ALA49L-ANTGYW

all sfx
except NX300h

Part Number:

Steel: PZ4AL-2793-00
Aluminium: PZ4AL-2794-00



Weight:

Steel: 14.10 kg
Aluminium: 10.09 kg




Installation Time:

30 min

Rev.1 12.10.2015


PZ4AL-02793-00, PZ4AL-02794-00

A



PZ4AL-02793-60

B




1x

C




1x

D




1x

E




1x

F



1x

G



M10x30

5x


H



d=10

5x


I



d=10


5x

J




h=10


1x





17 mm





1




FWD




see repair manual




2






FWD




3




4




5





FWD




6



FWD




D



1




7




3

17 mm



4



45 Nm

2




1



E




8




FWD

3

17 mm



4



45 Nm

2




1



F



9




FWD







see repair manual





10



FWD



11



12

